

UNIVERSAL CONVERTER GUIDELINES

The Universal Catalytic Converters in this catalog can be used for vehicle applications not included in this catalog, provided the following requirements are met:

1. The installer must use the same replacement converter type as the Original Equipment Converter.
 - A. There are three converter types:
 1. Two-way or oxidation
 2. Three-way
 3. Three-way plus oxidation or three way plus air or air tube converter.
 - B. The vehicle's type of Original Equipment Converter will be identified on the Emission Family Code label located in the engine compartment. The following codes will be found in the label's catalyst section.
 1. OC or COC-Two-way
 2. TWC or ORC- Three-way
 3. TWC/OC or ORC/OC-Three-way plus oxidation
2. The vehicle's engine displacement and weight must not exceed those approved for the consolidation converters listed. Weight is equal to the gross vehicle weight less the vehicle capacity plus 300 lbs. The gross vehicle weight and vehicle capacity may be found on a tag inside the vehicle door or in the owner's manual.